

## Technical Data Sheet



**HZBEV12-18**

**A.G.M. Battery**



<b>Voltage</b>	<b>12v</b>
<b>Cold cranking amps</b>	<b>214</b>
<b>Reserve capacity 20 amps</b>	<b>27</b>
<b>Capacity @ 20 HR</b>	<b>17.4ah</b>
<b>Capacity @ 48 HR</b>	<b>18.8ah</b>
<b>Capacity @ 5 HR</b>	<b>14.2ah</b>
<b>Tab or Thread insert</b>	<b>Thread</b>
<b>Thread insert size (mm)</b>	<b>5mm</b>
<b>Bench charge rate</b>	<b>2amp</b>

**Dimensions (mm)      Weight (kg)**

<b>Length</b>	<b>181</b>	<b>5.5</b>
<b>Width</b>	<b>76</b>	
<b>Height</b>	<b>167</b>	

**To ensure maximum cycle life it is important to ensure the battery is fully re-charged as soon as possible after use.**

**The following is a guide to the number of cycles that can be expected.**

**100% D.O.D = 270 cycles: 75% D.O.D = 350 cycles 50% D.O.D = 550 cycles.**